

AIRBUS	JOB CARD		MPD-TASK: 212652-01
	SNR - A318/A319/A320/A321		AMM TASK : 21-26-52-000-802-A 21-26-52 PB 401
A/C Reg.: VP-BED	TITLE: 21-26-52-000-802-A - Removal of the Avionics-Ventilation Skin Air-Inlet-Valve for in Shop Overhaul		
CARD:	ZONE: 127	INTERVAL:	
SKILL:	ACCESS:		

	MECH.	INSP.												
** ON A/C ALL TASK 21-26-52-000-802-A Removal of the Avionics-Ventilation Skin Air-Inlet-Valve for in Shop Overhaul FIN : 15HQ 1. <u>Reason for the Job</u> Refer to the MPD TASK: 212652-01 REMOVE SKIN AIR INLET VALVE FOR IN SHOP OVERHAUL. <u>NOTE:</u> This task is only applicable on SAIV P/N VFT210B00 or P/N VFT210A2. 2. <u>Job Set-up Information</u> A. Work Zones and Access Panels <table border="1"> <thead> <tr> <th>ZONE/ACCESS</th> <th>ZONE DESCRIPTION</th> </tr> </thead> <tbody> <tr> <td>127</td> <td>REAR AVIONIC COMPARTMENT</td> </tr> </tbody> </table> B. Referenced Information <table border="1"> <thead> <tr> <th>REFERENCE</th> <th>DESIGNATION</th> </tr> </thead> <tbody> <tr> <td>(Ref. 21-26-52-000-001-A).</td> <td>Removal of the Avionics-Ventilation Skin Air-Inlet-Valve</td> </tr> <tr> <td>(Ref. 21-26-52-400-001-A).</td> <td>Installation of the Avionics-Ventilation Skin Air-Inlet-Valve</td> </tr> <tr> <td>(Ref. 21-26-52-400-001-A-01).</td> <td>Installation of the Avionics-Ventilation Skin Air-Inlet-Valve</td> </tr> </tbody> </table>	ZONE/ACCESS	ZONE DESCRIPTION	127	REAR AVIONIC COMPARTMENT	REFERENCE	DESIGNATION	(Ref. 21-26-52-000-001-A).	Removal of the Avionics-Ventilation Skin Air-Inlet-Valve	(Ref. 21-26-52-400-001-A).	Installation of the Avionics-Ventilation Skin Air-Inlet-Valve	(Ref. 21-26-52-400-001-A-01).	Installation of the Avionics-Ventilation Skin Air-Inlet-Valve		
ZONE/ACCESS	ZONE DESCRIPTION													
127	REAR AVIONIC COMPARTMENT													
REFERENCE	DESIGNATION													
(Ref. 21-26-52-000-001-A).	Removal of the Avionics-Ventilation Skin Air-Inlet-Valve													
(Ref. 21-26-52-400-001-A).	Installation of the Avionics-Ventilation Skin Air-Inlet-Valve													
(Ref. 21-26-52-400-001-A-01).	Installation of the Avionics-Ventilation Skin Air-Inlet-Valve													
3. <u>Job Set-up</u> Subtask 21-26-52-941-051-A A. Not applicable.														
4. <u>Procedure</u> Subtask 21-26-52-020-052-A A. Removal of the Skin Air-Inlet Valve for in Shop Overhaul (1) Remove the skin air-inlet valve (Ref. AMM TASK 21-26-52-000-001) . (2) Send the valve to the workshop for overhaul. (3) Install the skin air-inlet valve (Ref. AMM TASK 21-26-52-400-001) .														
*** END OF CARD ***														